

Patron[®]
Technology for better



2020

PATRON PRODUCT CATALOG

UR ENTERPRISES

HP 12A CARTRIDGE



HP CARTRIDGES



12A (Q2612A)



88A (CC388A)



78A/278A (CE278A)



85A/285A (CE285A/CANON 925)



30A (CF230A)



05A (CE505A)



28A/228A (CF228A)



80A/280A (CF280A)



11A (Q6411A)



14X (CF214X)

HP CARTRIDGES



15A (C7115A)



16A (Q7516A)



17A (CF217A)



18A (CF218A)



26A (CF226A)



29X (C4129X)



35A (CB435A/CANON 912)



36A (CB436A/CANON 313)



19A (CF219A/CF218A) DR



32A (CF232A/CF230A) DR

HP CARTRIDGES



33A/233A (CF233A)



49A (Q5949A)



43X (C8543X)



53A (Q7553A)



55A (CE255A)



56A (CF256A)



70A (Q7570A)



81A (CF281A)



93A (CZ192A)



87A (CF287A)

HP/CANON CARTRIDGES



64A/90A (CC364A/CE390A)



83X (CF283X / CANON CRG-337)



110A (W110A/W112A)



CANON 052H



CRG-337




CRG-303



CRG-128



FX9



NPG-28



NPG-51

BROTHER CARTRIDGES



TN450



DR420



TN2365



DR2365



TN2465



DR2465



TN350



DR350



TN360



DR360

BROTHER CARTRIDGES



TN550/620



DR520/620



TN720



DR720



TN820



DR820



TN1020



DR1000



TN-B021



DR-B021



TN3448



DR3400

SAMSUNG CARTRIDGES



101S (MLT D101S)



104S (MLT D104S) / 1043 / 1666



116S (MLT D116S) TONER



116DR (MLT D116) DRUM UNIT



1610 (ML 1610D)



111S (MLT D111S)



103S (MLT D103S)



105S (MLT D105S)



203L (MLT D203L)



108S (MLT D108S) / 1640

SAMSUNG CARTRIDGES



109S (MLT D109S) / 4300



110L (MLT D110L)



115L (MLT D115L)



3050 (ML 3050)



307 (MLT D307E) TONER



307 (MLT D307E) DRUM UNIT



2850 (ML 2850)



707L (MLT 707L)



205L 9MLT D205L)



209S (MLT D209S)

RICOH CARTRIDGES



SP 100/111



SP 200/210



SP 300




SP 310



SP 3410/3510



SP 3600



RICOH 2501 COPIER



RICOH 1230 COPIER



RICOH 2014 HS COPIER

HP COLOR LASER CARTRIDGES



HP 125A
CB540A/541A/542A/543A




HP 130A
CF350A/351A/352A/353A



HP 201A
CF400A/401A/402A/403A



HP 202A
CF500A/501A/502A/503A



HP 307A (5225) REMAND
CE740A/741A/742A/743A



HP 126A/130A
CE310A/311A/312A/313A



HP 304A
CC530A/531A/532A/533A



HP 647A/648A
CE260A/261A/262A/263A




HP 305A (M451)
CE410A/411A/412A/413A



HP 205A
CF510A/511A/512A/513A



HP 131A
CF210A/211A/212A/213A



HP 128A (1525K)
CE320A/321A/322A/323A

COPIER CARTRIDGES



KYOCERA TK-439



KYOCERA TK-477/479



KYOCERA TK-4109



KYOCERA TK-1114



LEXMARK X203/204



LEXMARK E260



TOSHIBA 1640 (T1640D)



TOSHIBA 181S (T1810C)



KNM TN116



KNM TN118



KNM TNP28 (1500/1580/1590)

INK CARTRIDGES



HP 920



HP 932/933



HP 934/935



HP 950/951



HP 685

INK CARTRIDGES



HP GT Series



CANON G Series



EPSON UNIVERSAL



EPSON 3110



HP 955 BK



HP 960 BK

RIBBON CARTRIDGES



EPSON PLQ20K



OLIVETTI PR2



EPSON LQ310




EPSON LQ800



DASCOM DS3200H/DS400



EPSON ERC30/ERC38



WIPRO DSI 5235




EPSON FX-2190



STAR BP3000/WINCOR 4915



TVSE SP40



**EPSON MX100/FX105 /
TVS136 COL**

HP OPC DRUM



Q2612A



CC388A



CF228A/CF226A/CF287A



CE505A/CF280A



Q5949A/Q7553A



CE255A



CF256A/56X



CF219A/CF232A



Q7516A



C7115A



C4129X



CB540A/1212/1215



CE314A/1025



CE740A/5225

BROTHER/CANON OPC DRUM

BROTHER

CANON



TN420/450/TN2365



IR 2016/NPG-28



TN1020



IR 3300/NPG-18



TN620



IR 2270



TN360



IR 2525/NPG-51

SAMSUNG OPC DRUM



1610



1666




101



103/115/116/205/2830




2850/1053



3470/3050



1710/109



1210



707

OPC DRUM



RICOH SP100/111/200



RICOH SP300/310/3410/3510



RICOH AFICIO MP2000/1015



PANASONIC 1500



LEXMARK E260



LEXMARK X203

PCR - HP



12A



88A



05A/80A



53A/49A



55A



28A/26A/87A



19A/32A



56A

PCR - HP



29X



92A/93A



16A



70A



1025



1215



1515



CE260A

PCR - SAMSUNG



101



1610/1640



1666/104



109/4300



116/2876



115/2830



103



2850



205/3310

PCR



RICOH 100/111



RICOH 200/210



RICOH 300/310



RICOH 3410/3510



LEXMARK 203/204



LEXMARK 260/264



CANON IR 2016

MAGNETIC ROLLER



12A/Q2612A



88A/CC388A



49A/53A



05A/80A



15A/C7115A



28A/87A/226A



17A/18A/30A



29X/C4129X



55A/CE255A



70A, 16A, 92A/93A



90A/64A/81A

DEVELOPER ROLLER



HP 1025/1212/1215/ CB540



RICOH SP100/111



SAM 1610 /1640 /108



SAM 1666/1043 /104



SAM 101/111/110



SAM 205/3310



SAM 203/3320



SAM 116 /2830/103/115




BROTHER TN450/420,
TN2365/660, KONICA 1500




BROTHER TN750

WIPER/DOCTOR BLADES




12A/Q2612A




88A/CC388A



49A/53A




05A/80A



16A/92A/93A




29X/C4129X




15A/C7115A



28A/228A/CF228A



55A/CE255A



HP 1025/1215

POWER SUPPLY BOARD




HP 1020 / CANON LBP 2900




HP M1005 (NEW MODEL)



HP M1005 (OLD MODEL)



HP 128



HP 1108




HP 1136



HP 1566


ENGINE CONTROL UNIT (DC BOARD)



HP 1020 / CANON LBP 2900



HP M1005 (NEW MODEL)



HP M1005 (OLD MODEL)

FORMATTER BOARD: USB BOARD or LOGIC BOARD/CARD



HP 1020




HP 1136



HP 128



HP 1108



M1005 (New Model)



M1005 (Old Model)



CANON LBP 2900

FUSER UNIT / FUSER ASSEMBLY



LJ 1020



LJ1020 FUSER GUIDE



LJ P1007



LJ P1007 FUSER GUIDE



LJ M1005



LJ M1136



P1566



HP 425

LASER SCANNER ASSEMBLY



HP LJ 1020



HP LJ 1007



HP LJ M1136



HP LJ P1606

UPPER SCANNER UNIT/CCD SCANNER ASSEMBLY



HP LJ M1005 (NEW MODEL)



HP LJ M1005 (OLD MODEL)



HP LJ M1136



HP LJ M1213

CCD GEAR BOX



HP LJ M1005 (NEW MODEL)



HP LJ M1005 (OLD MODEL)

SCANNER CABLES



LJ M1005 (HP M1005 MFP)



LJ M128 (HP M128)



SJ 200 (HP SCANJET 200)



EPSON L210



SAMSUNG SCX 4300



SAMSUNG SCX 4521



CANON 4820




CANON IMAGECLASS 3010

CABLES



Control Panel Cable
HP LJ M1005 MFP




Control Panel Cable
CANON 4570



Encoder EPSON L210



Print Head Cable EPSON L210



Print Head Cable FX 2175



Print Head Cable LX 310



Print Head Cable
LX 800 DX



Print Head Cable
LX 1050-300



Timing Belt EPSON L210

GEAR & BUSH



LJ 1020
PRESSURE ROLLER GEAR



LJ P1007
PRESSURE ROLLER



LJ P1606
PRESSURE ROLLER GEAR



LJ 1020
FUSER DRIVE GEAR



LJ P1007
TONER DRIVE GEAR



LJ P1606
FUSER DRIVE GEAR



LJ 1020
CLUTCH DRIVE GEAR



LJ P1007
CLUTCH DRIVE GEAR



LJ P1606
CLUTCH GEAR



LJ 1020
MOTOR DRIVE GEAR



P1007
PRESSURE ROLLER BUSH



LJ 1010
PRESSURE ROLLER



LJ 1020
CLUTCH GEAR



LJ P1007
BELT DRIVE GEAR



LJ P1008
CLUTCH GEAR



LJ 1020 Toner Driver
Gear Bush



SAMSUNG ML 1666
LOWER ROLLER GEAR



SAMSUNG ML 1666
UPPER ROLLER GEAR

LOWER SLEEVED ROLLER (PRESSURE ROLLER)



LJ 1020 (12A)



LJ 1008 (88A)



LJ 1606 (78A)



LJ 1320 (49A/53A)



LJ 2035 (05A/80A)



LJ 1022 (HP 1022/FX9)



LJ 5200 (16A)



SAMSUNG 1666/2161



SAMSUNG 1610



RICOH SP 200



BROTHER 2240



BROTHER 5350

UPPER ROLLER



SAMSUNG 1666/1610



SAMSUNG ML 2850/SCX 4521



SAMSUNG ML 2876



SAMSUNG ML 3471




RICOH SP 100




RICOH SP 200



BROTHER HL 2240



BROTHER HL 2541



BROTHER HL 5350

PAPER PICK-UP ROLLER



LJ 1010 (HP 12A)




LJ P1007 (HP 88A)



LJ P1505 (HP 78A)



LJ 2035
(HP 05A) TRAY 1



LJ 2035
(HP 05A) TRAY 2



LJ 1160 (HP 49A)



LJ P3015
(HP 55A) TRAY 1



LJ P3015
(HP 55A) TRAY 2



LJ 5200 (HP 16A)
TRAY 2



LJ 5000
(HP 29X) TRAY 1




LJ 5000
(HP 29X) TRAY 2

PAPER PICK-UP ROLLER



SAMSUNG 1610



SAMSUNG 4300 (FEED TIRE)



SAMSUNG SCX 4521FS



EPSON L210 (BIG)



EPSON L210

TOP COVER



LJ 1020 Top Cover



LJ P1007



LJ 1020 Fuser Cover



CANON LBP 2900



LJ M1005
Scanner Top Cover

PAPER INPUT TRAY




HP 1020



HP M1005




HP 1008



HP 1213/1136



HP 126



CANON LBP 2900


PAPER OUTPUT TRAY



HP 1020




HP 1008




HP M1005



HP 1213/1136



HP 126



CANON LBP 2900

PAPER INPUT/OUTPUT TRAY



HP 1020



HP M1005



HP 1008



HP 1213/1136



HP 126



CANON LBP 2900

PRINTER ACCESSORIES

SEPARATION PAD



HP LJ 1020
CANON LBP 2900



SAMSUNG
ML 1610 / SCX 4521

SOLENOID



HP LJ 1020



HP LJ P1007



SAMSUNG SCX-4521

WASTE INK PAD



EPSON L380



EPSON M100



EPSON L800

HP 12A CARTRIDGE

